



RHINO-RACK


CONTROLLED

RSK04

| Item | Component RSK05 | Qty | Part No. |
|------|------------------------|-----|----------|
| 1 | RSB Locking Strap Long | 4 | CA1320 |
| 2 | Locking Barrel | 4 | - |
| 3 | Metal Key | 2 | - |
| 4 | 4mm Allen Key | 1 | H049 |
| 5 | RSB Gasket Round | 4 | M873 |

Note:

RBK04 is intended for use with RSB01S/B, RSB02S/B, RSB03S/B, RSB04S/B, RSB05S/B, RSB06S/B and RSB07S/B. Refer to R504 Stealth Bar instructions for installation.



Issue: 01

Document No: R1352

Prepared: Kayle Everett



RHINO-RACK


CONTROLLED

RSK04

| Item | Component RSK05 | Qty | Part No. |
|------|------------------------|-----|----------|
| 1 | RSB Locking Strap Long | 4 | CA1320 |
| 2 | Locking Barrel | 4 | - |
| 3 | Metal Key | 2 | - |
| 4 | 4mm Allen Key | 1 | H049 |
| 5 | RSB Gasket Round | 4 | M873 |

Note:

RBK04 is intended for use with RSB01S/B, RSB02S/B, RSB03S/B, RSB04S/B, RSB05S/B, RSB06S/B and RSB07S/B. Refer to R504 Stealth Bar instructions for installation.



Issue: 01

Document No: R1352

Prepared: Kayle Everett



RHINO-RACK


CONTROLLED

RSK04

| Item | Component RSK05 | Qty | Part No. |
|------|------------------------|-----|----------|
| 1 | RSB Locking Strap Long | 4 | CA1320 |
| 2 | Locking Barrel | 4 | - |
| 3 | Metal Key | 2 | - |
| 4 | 4mm Allen Key | 1 | H049 |
| 5 | RSB Gasket Round | 4 | M873 |

Note:

RBK04 is intended for use with RSB01S/B, RSB02S/B, RSB03S/B, RSB04S/B, RSB05S/B, RSB06S/B and RSB07S/B. Refer to R504 Stealth Bar instructions for installation.



Issue: 01

Document No: R1352

Prepared: Kayle Everett



RHINO-RACK


CONTROLLED

RSK04

| Item | Component RSK05 | Qty | Part No. |
|------|------------------------|-----|----------|
| 1 | RSB Locking Strap Long | 4 | CA1320 |
| 2 | Locking Barrel | 4 | - |
| 3 | Metal Key | 2 | - |
| 4 | 4mm Allen Key | 1 | H049 |
| 5 | RSB Gasket Round | 4 | M873 |

Note:

RBK04 is intended for use with RSB01S/B, RSB02S/B, RSB03S/B, RSB04S/B, RSB05S/B, RSB06S/B and RSB07S/B. Refer to R504 Stealth Bar instructions for installation.



Issue: 01

Document No: R1352

Prepared: Kayle Everett



RHINO-RACK


CONTROLLED

RSK04

| Item | Component RSK05 | Qty | Part No. |
|------|------------------------|-----|----------|
| 1 | RSB Locking Strap Long | 4 | CA1320 |
| 2 | Locking Barrel | 4 | - |
| 3 | Metal Key | 2 | - |
| 4 | 4mm Allen Key | 1 | H049 |
| 5 | RSB Gasket Round | 4 | M873 |

Note:

RBK04 is intended for use with RSB01S/B, RSB02S/B, RSB03S/B, RSB04S/B, RSB05S/B, RSB06S/B and RSB07S/B. Refer to R504 Stealth Bar instructions for installation.



Issue: 01

Document No: R1352

Prepared: Kayle Everett



RHINO-RACK


CONTROLLED

RSK04

| Item | Component RSK05 | Qty | Part No. |
|------|------------------------|-----|----------|
| 1 | RSB Locking Strap Long | 4 | CA1320 |
| 2 | Locking Barrel | 4 | - |
| 3 | Metal Key | 2 | - |
| 4 | 4mm Allen Key | 1 | H049 |
| 5 | RSB Gasket Round | 4 | M873 |

Note:

RBK04 is intended for use with RSB01S/B, RSB02S/B, RSB03S/B, RSB04S/B, RSB05S/B, RSB06S/B and RSB07S/B. Refer to R504 Stealth Bar instructions for installation.



Issue: 01

Document No: R1352

Prepared: Kayle Everett