

R1236 - Supplement: Toyota Hilux 4dr Ute Double Cab 10/15 on Genuine Canopy

CONTROLLED



Toyota Hilux 4dr Ute Double Cab 10/15 On

Use masking tape to cover the sides of the canopy in the approximate working area. Position the track 80mm from the front of the canopy and 40mm out from the top edge of the side windows as shown. (a) Mark a line on the tape on the canopy at the end of the tracks. Mark a centre line of the C channel on both ends of each track. Move the track out slightly and use it as a straight edge to join the two centre line points.

IMPORTANT: Refer to table below for front & side measurements prior to drilling. LOAD RATING: 80kg

Vehicle	Kits Used
Hilux 10/15 on Double Cab	RTC12 x 1, RLTF x 1 (rear), RLTP x 1 (front), VA126B x 2. Pioneer Tray 42109B can also be used.



Measurements		
X	Front	80mm
Y	Side	40mm




R1236 - Supplement: Toyota Hilux 4dr Ute Double Cab 10/15 on Genuine Canopy

Mark end holes 15mm in from end of tracks (the center of the T-bolt is placed 15mm from the end of the tracks). Spacing for T-bolt holes to be no greater than 234mm. Refer diagram (fig a). Using a sharp $\text{Ø}6.5\text{mm}$ drill bit, hold the drill perpendicular to the surface of the canopy, apply minimal pressure and proceed to drill. Remove any swarf with a vacuum.


Fig a.



1: Drill with a 6.5mm drill bit.



2: Vacuum any swarf from the roof.



Note: Now follow RTC12 instructions for completion of track, legs and crossbars.